

# VC999<sup>®</sup> C6 Medical

---



## GMP-Audittrail

**With a complete recording of all user accesses and actions, a transparent and secure record of changed Data is provided**

### **BENEFITS:**

- Complete recording of operator actions, error messages and process data
- Individual operator login with Password or USB Key
- Process data files (.txt or .pdf) are retrievable with a USB Drive or network connection.
- Barcode scanner for order data acquisition
- Remote access (e.g. for remote maintenance)

In combination with bags, pre-validated by VC999<sup>®</sup>, for PAPE, Tyvek<sup>®</sup> and Paper/film with a shelf-life of up to 10 years, our machine forms the perfect unit for every customer application in medical technology.

### **Your advantage when using our process:**

No need for your own expensive and time-consuming packaging validation, start immediately.

# VC999<sup>®</sup> C6 Medical

## An Overview of our Highlights

- Compliance with all international medical technology standards
- Cleanroom compatible with powerful external high-speed vacuum pump
- High performance sealing machine for all types of medical packaging types such as Tyvek<sup>®</sup> PA/PE, Paper/Film, e.g. one machine for nearly all applications
- 10mm sealing seam
- IQ / OQ / PQ qualified, closest tolerances guaranteed
- Requalification by our trained VC999 Service Team
- Monitoring of temperature, pressure, time and vacuum. All parameters qualified
- Illumination of the complete sealing chamber
- PLC control
- Control panel with touch screen at a comfortable operating height, robust construction
- Intuitive user interface similar to a smartphone
- USB connection for recipe management
- Soft-Air pre-ventilation, prevents piercing of bags by sharp-edged products
- Hygienic and easy to clean thanks to even surfaces made of stainless materials.
- Automatic lid drive

### Technical Data

### VC999<sup>®</sup> C6 Medical

Outside dimensions of machine without panel	1172 x 1087 x 970 (w x h x d)
Sealing bar length	Front 888 mm, right and left 448 mm
Number of sealing bars	3
Max. possible product dimensions	approx. length 890 mm, width 490 mm, height 175 mm
Power connection	400 V / 3 / 50 Hz / 9 kW / 25 AT
Compressed air connection	5-6 bar, $\varnothing$ inside 9 mm
Vacuum pump	200 m <sup>3</sup> /h
Weight machine, pump included	505 kg
Gas flushing (MAP)	Optional $\varnothing$ inside 7 mm

Technical changes reserved

